

- Aftertouch 60
Alpha dial 54
Alternate controller 61
Ambience 27
Amp *see amplifier*
Amplifier 10
Attack 42-43, 66
Aux returns *see auxiliary returns*
Auxiliary returns 20, 27, 33, 37
Aux sends *see auxiliary sends*
Auxiliary sends 19-20, 27, 33, 37
Band 13-14
Bank buttons 54
Bass 13
Breath controller 61
Chamber 32
Channel 4
Chorus 36-37
Chorus depth 36
Chorus mix 37
Chorus rate 36
Compressor 41-44
Console *see mixer*
Cutoff 65-66
Decay 66
Decay time 33
Decibel 41-42
Delay 27-28
Delay time 27, 36
Desk *see mixer*
Diaphragm 9
Diffusion 33
Digital chorus *see chorus*
Digital delay *see delay*
Dynamic level 41
Dynamic range 41
Echo 26-27
EQ *see equalization*
Equalization 13-14, 19
Expression pedal 59
Faders 4-5
Fc *see cutoff*
Feedback 27
Filter cutoff *see cutoff*
Filter sweep 65
Foldback *see auxiliary sends*
Footswitch 59
Gain 4
Gain reduction meter 42
General MIDI 55
Graphic EQ 13-14, 19
Hall 32
Hand-held microphone 9
Headphone jack 5
Hi 13
Home keyboard 50
Increment/decrement buttons 54
Input 4
Insert 19, 28, 37
Insert cable 19
Jack 4
Knob 4
Limiter 44
Line level 9
Lo 13
Makeup gain 43
Master gain controls 4-5
Mic *see microphone*
Mic cable 9
Microphone 9-10
Mid 13
MIDI 50
Milliseconds 27
Mixer 4-5, 9-10, 18-20
Modulation wheel 60-61
Monitor 20
Mono delay 27
Monophonic synthesizer 49, 55
Mono sounds 55
Mother keyboard 50
Multitimbral synthesizer 50
Mute 18

Number buttons 54
Output 4
PA system 10
Paddle 61
Pan 5
Patch 49, 54-55, 66
Pedalboard 59
Phantom power 20
Ping-pong delay 28
Pitch bend 60
Plate 32
Polyphony 49
Preamp *see preamplifier*
Preamplifier 9-10, 18-19
Predelay 32-33
Programming 65-66
Pulse wave 54
Q see resonance
Rack 4
Rack screws 4
Ratio 42
Realtime controls 59-61
Regeneration *see resonance and feedback*
Reverb *see reverberation*
Reverb time *see decay time*
Reverberation 32-33
Refraction 26
Release 42-43, 66
Release velocity 60
Repeat *see feedback*
Resonance 65
Ribbon controller 61
Room 32
Shelving EQ 13, 19
Save *see write*
Saw wave 54
Sine wave 54
Solo 18
Solo level 18
Sound waves 26
Speaker 9-10
Specialized synthesizer 54
Square wave 54
Stereo 4
Stereo Delay 27-28
Stick 61
Sustain 66
Synthesizer 4, 49-50, 65-66
Threshold 41
Tone module 50
Treble 13
Trim 19
Velocity 60
Write 66
XLR connector 9-10, 18-19
X-Y pad 61